VOLVO

Schedule of Factory Maintenance Service Operations

2026 PHEV/MHEV Models

V60CC • V90CC • XC40 • XC60 • XC90



Complimentary factory scheduled maintenance covers the first two (2) regularly scheduled maintenance services at 10,000 and 20,000 miles.

Every 10,000 Miles

- ☐ **Engine Oil and Filter: Replace**
- ☐ **Service Reminder Indicator (SRI): Reset**
  Clears codes for next scheduled service.
- ☐ **Engine Coolant: Check/Adjust Antifreeze Rating and Anti-Corrosion Agent**
- ☐ **Automatic Transmission Control: Check Park/Neutral Position (PNP) Switch**
- ☐ **Washer Fluid: Check/Adjust**
- ☐ **Check all wiper blades and washer systems for both windshields and headlights for functionality and signs of wear.**
- ☐ **External Lighting: Check**
- ☐ **Horn: Check Function**
- ☐ **Seatbelts: Check Function**
- ☐ **Brake Fluid Level: Check/Adjust**
- ☐ **Brake Fluid: Check and Adjust (hygroscopic and level)**
  At customer's expense
- ☐ **Brake Pads/Discs: Check**
- ☐ **Wheels and Tires: Check Wear and Condition**
- ☐ **Spare Tire Check for Damage, Wear, and Tire Pressure**
  Check spare tire pressure (where applicable) every 2 years or every 40,000 miles.

Every 20,000 Miles (20, 40, 60, 80, 100, 120, 140)

- ☐ **Engine/Transmission/Timing Gear: Check for Leaks**
  In the event of a leak from the transmission, check the oil level.
- ☐ **Automatic Transmission Fluid Level: Check for Leaks/Adjust**
- ☐ **Headlights, Fog Lights: Check and Align**
- ☐ **Cabin Air Filter: Replace**
  Volvo recommends that the filter be replaced at least once a year or more often in heavy traffic and dirty/dusty areas.
- ☐ **Wheels and Tires: Check Inflation Pressure**
- ☐ **Reset Tire Pressure Monitor System**
- ☐ **Inside of Windshield in Front of Camera: Clean**
  Vehicles with camera for collision warning. First 20,000-mile service only.

Every 40,000 Miles (40, 80, 120)

- ☐ **Fuel Lines and Fuel Filter: Check for Leakage And Damage**
- ☐ **Engine Air Cleaner (ACL): Clean the Air Cleaner Housing/Replace Filter**
  May be necessary to change more frequently when driving in dusty/dirty areas.
- ☐ **Steering/Front Suspension: Check for Wear**
- ☐ **Rear Suspension: Check for Wear**
- ☐ **Final Drive/Bevel Gear: Visual Inspection, Check for Leaks**
  Only check the level if there is leakage. (All-wheel Drive Models Only)
- ☐ **Driveshaft Joints: Check for Wear/Play**
- ☐ **Driveshafts: Check Rubber Boots**
- ☐ **Propeller Shaft, Pilot Bearing and Universal Joints: Check Wear**
  (All-wheel Drive Models Only)
- ☐ **Brake Hoses and Lines: Check for Damage/ Leaks**

Every 60,000 Miles (60, 120)

- ☐ **Spark Plugs: Replace**

Every 150,000 Miles

- ☐ **Accessory Drive Belt, Belt Tensioner and Idler Pulley: Replace**
  Replace at 150,000 miles or 10 years, whichever comes first.
- ☐ **Timing Belt Tensioner and Idler Pulley: Replace**
  Replace at 150,000 miles or 10 years, whichever comes first.

General

- ☐ **Software and Parts: Check/Replace**
  Check and replace parts or software, as required by Volvo Car USA, LLC, that are covered under the terms of the Volvo New Car Warranty. For service intervals beyond 150,000 miles, consult your authorized Volvo dealer.



Important: Only full synthetic oil meeting ACEA A5/B5 requirements should be used. Lower quality oils may not offer the same engine performance or engine protection.

Source: Volvo Warranty and Service Records Information.